

# ИНСТРУКЦИЯ ПО МОНТАЖУ ABBER Schwarzer Diamant


AG30100BH/AG30110BH/AG30120BH/AG30130BH/AG30140BH/  
AG30150BH/AG30160BH/AG30170BH

## НЕОБХОДИМЫЕ ИНСТРУМЕНТЫ




## СПИСОК ДЕТАЛЕЙ

X2	X1	X1	X2	X2	X2	X2
X2	X1	X2	X1	X1	X2	X8
4X30	X16	4X16	X4	4X10	X2	4X12
				X4	$\Phi 3.2$	X1




1





РАЗМЕР	A(ММ)
1000	990-1020
1100	1090-1120
1200	1190-1220
1300	1290-1320
1600	1590-1620
1700	1690-1720



2





3



4



5



6

